

Historic, Archive Document

Do not assume content reflects current scientific knowledge, policies, or practices.

aSB763.C2F45

Forest Service

Forest Pest
Management
2810 Chiles Rd., Ste. B
Davis, CA 95616



Drop Size Spectra - Micronair AU5000 Atomizer And Hollow Cone Nozzles With Special Tank Mix



February 1986

FPM 86-5

February 1986

Drop Size Spectra – Micronair AU5000 Atomizer And Hollow Cone Nozzles With Special Tank Mix

Prepared by:

W. E. Yates

R. E. Cowden

Agricultural Engineering Department
University of California
Davis, CA 95616

Prepared for:

U.S. Department of Agriculture
Forest Service
Forest Pest Management
2810 Chiles Road, Suite B
Davis, CA 95616
(916)758-4600

John W. Barry
Project Leader

Purchase Order No. 40-01S8-0825
(Work under this purchase order
was completed in September 1985)

Pesticide Precautionary Statement and Disclaimer

This publication reports research involving pesticides or their simulants. It does not contain recommendations for their use, nor does it imply that the uses discussed here have been registered. All uses of pesticides must be registered by appropriate State and/or Federal agencies before they can be recommended.

CAUTION: Pesticides can be injurious to humans, domestic animals, desirable plants, and fish or other wildlife - if they are not handled or applied properly. Use all pesticides selectively and carefully. Follow recommended practices for the disposal of surplus pesticides and pesticide containers.

Information contained in this report has been developed for the guidance of employees of the Forest Service, U.S. Department of Agriculture, its contractors, and its cooperating Federal and State agencies. The Department of Agriculture assumes no responsibility for the interpretation or use of this information by other than its own employees.

The use of trade, firm, or corporation names is for the information and convenience of the reader. Such use does not constitute an official evaluation, conclusion, recommendation, endorsement, or approval of any product or service to the exclusion of others which may be suitable.

PREFACE

The purpose of this wind tunnel test was to establish atomization characteristics of special aerially applied tank mixes used in a sub-study of Program WIND. The objective of the sub-study was to compare different application techniques (nozzles and aircraft) to canopy penetration and spray deposition on manikins and equipment. Drop spectra of sprays must be determined at the nozzle where atomization occurs. This then makes it possible to establish base-lines and to evaluate nozzles on a comparative bases. Another important use of these data is as input to spray dispersion models which predict the dispersion of sprays. Spray dispersion models move each drop size through the atmosphere; therefore, for effective predictions it is essential to know the drop spectra of the tank mix.

Table of Contents

	Page
Preface	i
Table of Contents	ii
Introduction	1
Results	2
Summary	2
Table I - Test conditions for drop size measurements with the hollow cone nozzles	4
Table II - Test conditions for drop size measurements with the rotary atomizer	4
Table III - Summary of drop size spectrum from the three atomizers with selected mixtures	4
Table IV - Droplet spectra for D2-45 nozzle atomizing $MnSO_4$, Rhodamine BX, and water	5
Figure I - Droplet spectra data for a D2-45 nozzle atomizing $MnSO_4$, Rhodamine BX, and water	6
Table V - Droplet spectra for D4-45 nozzle atomizing $MnSO_4$, Rhodamine BX, and water	7-8
Figure II - Droplet spectra data for a D4-45 nozzle atomizing $MnSO_4$, Rhodamine BX, and water	9
Table VI - Droplet spectra for Micronair AU5000 rotary atomizer atomizing a tank mix of $MnSO_4$, Rhodamine BX, Nalco-Trol, and water	10
Figure III - Droplet spectra data for Micronair AU5000 rotary atomizer atomizing $MnSO_4$, Rhodamine BX, Nalco-Trol, and water	11

Introduction:

Tests were conducted in a wind tunnel to measure the drop size spectra from a D2-45 hollow cone nozzle and a D4-45 hollow cone nozzle with a tank mixture of 10 lbs. of technical grade Manganese sulfate (MnSO_4) plus 48 oz. Rhodamine BX dye in 100 gal. of water. Also a Micronair AU500 rotary atomizer was tested with a tank mixture of 10 lbs. technical grade MnSO_4 plus 3 oz. Nalco-Trol plus 48 oz. Rhodamine BX dye in 100 gal. water.

Equipment:

The tests were conducted in a wind tunnel at the University of California, Department of Agricultural Engineering. The wind tunnel has a test section 8 ft. long and a 2 x 2 ft. cross section. A Particle Measurement System (PMS) probe, OAP-2D-GA1, with a PMS 11-C data acquisition system was used to measure the drop size spectra. The probe has a nominal class size of 33 μm . The system counts and classifies the drops into 62 size classes from 28 to 2062 μm .

Procedures:

The drop size spectra was measured from a D2-45 hollow cone nozzle directed with the airstream at an airspeed of 25 mph and a D4-45 hollow cone nozzle directed with the airstream at 17 mph, Table I. We were unable to perform tests with the nozzles directed 90° to the airstream because the tunnel velocity was not sufficient to turn the particles with the direction of the airflow before they struck the bottom of the tunnel. We feel, however, that the particle size would not be significantly different at such a low airspeed velocity. The nozzles were mounted on a microprocessor controlled mechanism that could move the nozzle to scan the entire spray pattern.

The drop size measurement procedures for the Micronair AU5000 atomizer were similar to protocol developed for testing rotary atomizers described in earlier Forest Pest Management reports by the same authors. Briefly, the PMS probe was mounted in the wind tunnel with the laser beam located 5.25 inches

above the bottom of the wind tunnel test section and 12" downstream from the rear of the rotary atomizer. The atomizer was mounted on an adjustable vertical shaft such that the unit could be moved to a series of radial distances from the laser beam. Sample positions were calculated based on radial locations to represent the center of equal size sample areas. A single nozzle test involved taking a sample at six to nine sample positions, based on the size of the spray pattern. The reports for the different positions were combined into one composite pattern that represents the overall temporal drop size distribution for the atomizer. The Micronair AU5000 rotary atomizer was tested at an airspeed of 95 mph and blade angle of 40° , Table II.

Results:

Table III is a summary of the drop size spectra for the two formulations. The nomenclature used is as follows:

$D_{V.1}$ = Diameter that contains 10% of volume in drops of smaller size.

$D_{V.5}$ = Diameter that contains 50% of volume in drops of smaller size.

(Volume median diameter)

$D_{V.9}$ = Diameter that contains 90% of volume in drops of smaller size.

$$\text{Relative Span} = \text{R.S.} = \frac{D_{V.9} - D_{V.1}}{D_{V.5}}$$

The appendix contains the complete results of the drop size frequency data, statistical results and graphs for each of the 3 tests.

Summary:

Three tests were conducted using two hollow cone nozzles, a D2-45, D4-45 and a Micronair AU5000 Spinner. The two tests using the hollow cone nozzles were conducted using a tank mixture of 10 lbs. technical grade MnSO_4 plus 48 oz. Rhodamine BX dye in 100 gal. water. The test using the Micronair was conducted with a tank mix of 10 lbs. technical grade MnSO_4 plus 3 oz. of Nalco-Trol plus 48 oz. Rhodamine BX dye in 100 gal. water.

The drop size from the hollow cone nozzles are very similar to the previous tests with water (MEDC Report Measurement of Drop Size Frequency From Nozzles Used For Aerial Application Of Pesticides In Forests, Oct. 1984, Missoula, MT.). For example, results with the D4-45 nozzle at 40 psi, 0°, and 100 mph airstream with water produced a $D_{V.5}$ of 255 μm compared to 264 μm for the same nozzle with the MnSO_4 mixture and an airspeed of 95 mph. The AU5000 at 100 mph with water at 3 gpm and a blade angle of 35°, and 8000 rpm produced a $D_{V.5}$ of 118 μm . The test in this report had several different conditions, i.e., 95 mph airspeed, 5.9 gpm, 40° blade angle, 5575 rpm and a mixture of MnSO_4 and Nalco-Trol. As expected, the $D_{V.5}$ was somewhat larger, 189 μm , compared to the above test with water.

Table I

Test conditions for drop size measurements with the hollow cone nozzles.

Nozzle Type	Airspeed mph	Flowrate gpm	Pressure psi
D2-45	25	0.20	40
D4-45	17	0.47	70

Table II

Test conditions for drop size measurements with the rotary atomizer.

Atomizer Type	Airspeed mph	VRU Setting	Pressure psi	Flowrate gpm	Blade Angle	RPM
Micronair AU5000	95	13	50	5.9	40°	5575

Table III

Summary of drop size spectrum from the three atomizers with selected mixtures.

Atomizer Type	Tank Mixture	Drop size, μm			R.S.
		$D_{V.1}$	$D_{V.5}$	$D_{V.9}$	
D2-45	10 lbs MnSO_4 + 48 oz. Rh BX dye per 100 gal. H_2O	141	251	382	0.96
D4-45	10 lbs MnSO_4 + 48 oz. Rh BX dye per 100 gal. H_2O	138	264	410	1.03
Micro-nair	10 lbs MnSO_4 + 48 oz. Rh BX dye + 3 oz NalcoTrol per 100 gal. H_2O	104	189	307	1.07

TABLE IV

Droplet spectra for D2-45 nozzle atomizing MnSO_4 , Rhodamine BX, and water.

Nozzle	D2-45	Slice Rate	.75MHz
Angle to Airstream	0 degrees	AVG	100
Spray Pressure	40 psi	DFM	1 cm.
Airspeed	25 mph	BAR	1.5
Flow Rate	0.20 gpm	Distance to Probe	41 cm.
Tank Mix	10# Mn/100 gal H2O	Sample Interval	600 sec.
		Number of Samples	1
		Number of Scans	16
		Scan Spacing	2.3 cm.
		Scan Length	36.8 cm.

FILE: C:\PMS\DATA\100385.001
 Number of Tests Combined: 1

UPPER LIMIT	N(RAW)	N/SEC	Gm/SEC	%_N	%_VOL.	ACCUMULATED %_N	ACCUMULATED %_VOL.
56	3165	1.79E+06	0.06	32.30	0.46	32.30	0.46
89	7248	664949	0.13	12.02	1.03	44.32	1.49
122	9442	741717	0.45	13.41	3.52	57.73	5.01
154	11436	776556	1.06	14.04	8.30	71.77	13.30
187	9906	547396	1.42	9.90	11.06	81.66	24.36
220	7907	366417	1.60	6.62	12.51	88.29	36.88
252	6249	259948	1.77	4.70	13.83	92.99	50.70
284	4256	163589	1.64	2.96	12.83	95.94	63.53
318	2801	105922	1.52	1.91	11.89	97.86	75.42
351	1534	56879	1.11	1.03	8.68	98.89	84.10
382	857	31870	0.81	0.58	6.35	99.46	90.45
414	408	16292	0.54	0.29	4.19	99.76	94.64
447	165	6508	0.27	0.12	2.12	99.88	96.76
479	93	4063	0.21	0.07	1.64	99.95	98.40
512	42	1785	0.11	0.03	0.89	99.98	99.29
545	14	513	0.04	0.01	0.31	99.99	99.60
578	2	171	0.02	0.00	0.12	99.99	99.72
611	2	214	0.02	0.00	0.18	100.00	99.90
644	2	96	0.01	0.00	0.10	100.00	100.00

TOTAL 6.55E+04 5.53E+06 12.81

TOTAL ACCEPTED RAW PARTICLES / TOTAL IMAGES = 65529/ 43175 =151.8%

NUMBER MEAN DIA.= D_{10} 117.88 μm
 VOLUME MEAN DIA.= D_{30} 164.21 μm
 SAUTER MEAN DIA.= D_{32} 218.61 μm

NUMBER MEDIAN DIA.= $D_{N.1}$ <56 μm
 $D_{N.5}$ 102.92 μm
 $D_{N.9}$ 231.52 μm

VOLUME MEDIAN DIA.= $D_{V.1}$ 141.46 μm
 $D_{V.5}$ 250.83 μm
 $D_{V.9}$ 381.54 μm

RELATIVE SPAN= 0.96

Nozzle Type D2-45
 Angle to Airstream 0°
 Spray Pressure . . . 40 psi
 Airspeed 25 mph
 Flow Rate 0.20 gpm
 Tank Mix: 10# Mn/100 gal H2O

FILE: C:\PMS\DATA\100385.001






Figure I - Droplet spectra data for a D2-45 nozzle atomizing MnSO_4 , Rhodamine BX, and water.

TABLE V

Droplet spectra for D4-45 nozzle atomizing MnSO_4 , Rhodamine BX, and water.

Nozzle	D4-45	Slice Rate	.75MHz
Angle to Airstream	0 degrees	AVG	100
Spray Pressure	70 psi	DFM	1 cm.
Airspeed	17 mph	BAR	1.5
Flow Rate	.47 gpm	Distance to Probe	30 cm.
Tank Mix	10# Mn/100 gal H2O	Sample Interval	600 sec.
		Number of Samples	1
		Number of Scans	16
		Scan Spacing	2.3 cm.
		Scan Length	36.8 cm.

FILE: C:\PMS\DATA\10048510.002
 Number of Tests Combined: 2

UPPER LIMIT	N(RAW)	N/SEC	Gm/SEC	%_N	%_VOL_	ACCUMULATED	
						%_N	%_VOL_
56	7295	8.81E+06	0.29	46.63	0.87	46.63	0.87
89	12355	2.48E+06	0.49	13.10	1.47	59.73	2.34
122	11277	2.19E+06	1.33	11.57	3.96	71.30	6.30
154	9105	1.80E+06	2.46	9.52	7.35	80.82	13.65
187	6652	1.18E+06	3.05	6.24	9.10	87.05	22.75
220	5331	817821	3.58	4.33	10.69	91.38	33.44
252	4190	587418	4.00	3.11	11.95	94.49	45.39
284	2948	402517	4.04	2.13	12.07	96.62	57.46
318	2057	266388	3.83	1.41	11.44	98.03	68.90
351	1232	175875	3.44	0.93	10.27	98.96	79.17
382	667	88473	2.26	0.47	6.75	99.43	85.92
414	363	49423	1.63	0.26	4.86	99.69	90.78
447	191	30215	1.26	0.16	3.76	99.85	94.54
479	83	14598	0.76	0.08	2.26	99.93	96.80
512	39	6545	0.42	0.03	1.24	99.96	98.04
545	18	3831	0.29	0.02	0.88	99.98	98.92
578	7	1438	0.13	0.01	0.40	99.99	99.32
611	6	1570	0.17	0.01	0.51	100.00	99.83
644	1	392	0.05	0.00	0.15	100.00	99.98
677	0	0	0.00	0.00	0.00	100.00	99.98
710	0	0	0.00	0.00	0.00	100.00	99.98
743	0	0	0.00	0.00	0.00	100.00	99.98
776	0	0	0.00	0.00	0.00	100.00	99.98
809	1	24	0.01	0.00	0.02	100.00	100.00
TOTAL	6.38E+04	1.89E+07	33.49				

TABLE V (continued)

TOTAL ACCEPTED RAW PARTICLES / TOTAL IMAGES = 63818 / 60054 = 106.3%

NUMBER MEAN DIA. = D_{10} 97.29 μm
VOLUME MEAN DIA. = D_{30} 150.20 μm
SAUTER MEAN DIA. = D_{32} 220.29 μm

NUMBER MEDIAN DIA. = $D_{N.1}$ <56 μm
 $D_{N.5}$ <56 μm
 $D_{N.9}$ 209.38 μm

VOLUME MEDIAN DIA. = $D_{V.1}$ 138.22 μm
 $D_{V.5}$ 264.40 μm
 $D_{V.9}$ 409.72 μm

R.S. 1.03

Nozzle Type D4-45
 Angle to Airstream 0°
 Spray Pressure . . 70 psi
 Airspeed 17 mph
 Flow Rate47 gpm
 Tank Mix: 10# Mn/100 gal H2O

FILE: C:\PMS\DATA\10048510.002






Figure II - Droplet spectra data for a D4-45 nozzle atomizing MnSO_4 , Rhodamine BX, and water.

TABLE VI

Droplet Spectra for Micronair AU5000 rotary atomizer atomizing a tank mix of MnSO_4 , Rhodamine BX, Nalco-Trol, and water.

Nozzle	AU5000	Slice Rate	3 MHz
RPM	5575	AVG	20000
Spray Pressure	50 psi	DFM	1 cm.
Airspeed	95 mph	BAR	1.5
Flow Rate	5.9 gpm	Distance to Probe	32 cm.
Tank Mix	10# Mn, 3 oz NALCO/ 100 GAL H2O	Sample Interval	60 sec.
		Number of Samples	1
FILE: C:\PMS\DATA\10028515.002		Number of Sample Rings	8

Number of Tests Combined: 2

UPPER LIMIT	N(RAW)	N/SEC	Gm/SEC	% N	% VOL.	ACCUMULATED	
						% N	% VOL.
56	8705	2.37E+08	7.81	54.06	2.26	54.06	2.26
89	9742	6.07E+07	12.07	13.83	3.50	67.90	5.77
122	8710	5.19E+07	31.53	11.83	9.14	79.72	14.91
154	9762	4.13E+07	56.58	9.42	16.41	89.14	31.32
187	9960	2.39E+07	61.77	5.44	17.91	94.58	49.23
220	8141	1.19E+07	52.27	2.72	15.16	97.30	64.39
252	6587	6.28E+06	42.78	1.43	12.41	98.73	76.80
284	4594	3.38E+06	33.92	0.77	9.84	99.50	86.64
318	1970	1.18E+06	16.98	0.27	4.92	99.77	91.56
351	939	494299	9.67	0.11	2.80	99.88	94.36
382	541	233360	5.96	0.05	1.73	99.93	96.09
414	313	126749	4.17	0.03	1.21	99.96	97.30
447	208	75309	3.14	0.02	0.91	99.98	98.21
479	136	40484	2.10	0.01	0.61	99.99	98.82
512	91	30431	1.93	0.01	0.56	100.00	99.38
545	33	7428	0.57	0.00	0.17	100.00	99.55
578	23	7641	0.71	0.00	0.20	100.00	99.75
611	7	1370	0.15	0.00	0.04	100.00	99.79
644	11	4974	0.64	0.00	0.19	100.00	99.98
677	0	234	0.04	0.00	0.01	100.00	99.99
710	1	180	0.03	0.00	0.01	100.00	100.00

TOTAL 7.05E+04 4.39E+08 344.81

TOTAL ACCEPTED RAW PARTICLES / TOTAL IMAGES = 70474 / 96924 = 72.7%

NUMBER MEAN DIA. = D_{10} 78.82 μm
 VOLUME MEAN DIA. = D_{30} 114.51 μm
 SAUTER MEAN DIA. = D_{32} 161.62 μm

NUMBER MEDIAN DIA. = $D_{N.1}$... <56 μm
 $D_{N.5}$... <56 μm
 $D_{N.9}$... 159.52 μm

VOLUME MEDIAN DIA. = $D_{V.1}$... 104.22 μm
 $D_{V.5}$... 188.57 μm
 $D_{V.9}$... 306.85 μm

RELATIVE SPAN = 1.07

Nozzle Type . . . AU5000
 RPM 5575
 Spray Pressure . . 50 psi
 Airspeed 95 mph
 Flow Rate 5.9 gpm
 Tank Mix: 10# Mn, 3 oz NALCO/
 100 GAL H2O
 FILE: C:\PMS\DATA\10028515.002






Figure III - Droplet spectra data for Micronair AU5000 rotary atomizer atomizing MnSO_4 , Rhodamine BX, Nalco-Trol, and water.

NATIONAL AGRICULTURAL LIBRARY



1023166593